

Fitting a Fan Shroud

You will need

- Socket Set
- Screwdriver

This is an easy job which may be complicated if you dont take care.

Firstly undo the 2 bolts holding the front bumper to the top of the radiator.

Remove the 5 screws which hold the front lip cover on. Be careful because these screws are made of plastic and can round really easily - a stupid design fault. Once these clips are removed the cover will come off.

Place the fan shroud in place and refit all the screws and bolts. I found that it was better to replace the screws with metal bolts. Dont over tighten though cause it'll bend the shroud.

All in takes about 10-15minutes.

