

Fitting 'Eyebrows'



As supplied

You will need

- Eyebrows
- Bodypanel Tape
- Paintshop (if you want to)

This is an easy thing to do. You'll get these items supplied in black fibreglass with a good outer finish. As my FTO is black and I am a bit strapped for cash at the moment I decided to just put them on the car as they are and paint them sometime in the future.

Use body panel tape on the underside of the 'eyebrow' to fix it onto the light. I would recommend this as it's easy to take off if you decide to remove them, and it's strong enough to hold them. Fix on the underside and press them down onto the light. My left hand one was slightly warped and needed some force to lay flat, but the right hand side one was a perfect fit.

That's it!



Before



Tape on the underside



Fitted to light